



CICARBO™ GRAPHENE NANOMATERIALS



CELTIG, LLC is a Tennessee limited liability company founded to produce high-quality graphene nanosheets or flakes and to distribute commercial quantities of this line of products to markets worldwide. CELTIG manufactures 3 grades of nanomaterials suitable to a wide range of industrial applications. (See individual product data sheets for technical specifications.)

PRODUCT INFORMATION

- Form:** Light powder
- Color:** Dark gray to black
- Odor:** Odorless
- Carbon content:** Grade dependent (95.5 to 99.9%)
- Moisture content:** Grade dependent (< 2.0%)
- Ash content:** Grade dependent (0.1 to 4.5%)
- Dry powder resistivity:** < 100 ohm cm
- Sheet resistivity:** ~10 ohm/square (Grade dependent)
- Particle size range:** Grade dependent (100 nm to 10 μm)
- Mono-, bi-, and tri-layer content:** Grade dependent
- Dry powder density:** \approx 100 to 200 kg/m^3
- True density:** 2.2 g/cm^3
- Specific surface area:** Grade dependent (\approx 100 to 350 m^2/g)




MATERIAL CHARACTERIZATION



AFM image of single-layer graphene nanosheet

- ▶ The left image displays a single layer of graphene.
- ▶ Sheet dimension measures roughly 3-4 μm .
- ▶ The right image is the height trace of the nanosheet.
- ▶ Monolayer thickness is approximately 0.4 nm (4 \AA).



Typical nanosheet layer number distribution (Premium grade)




- ▶ Approximately 40% of nanosheets are monolayer.
- ▶ Approximately 33% are bilayer.
- ▶ Approximately 14% are trilayer.
- ▶ Minority of nanosheets range up to 7 layers in thickness.
- ▶ Distribution based on AFM images of > 300 nanosheets.



Typical nanosheet size number distribution

(Premium grade)

- ▶ Distribution based on AFM images of > 300 particles.
- ▶ Majority of nanosheets have sheet dimensions between 100 nm and 1.5 μm .
- ▶ Nanosheets dimensions range in size up to 6 μm .
- ▶ Nanoplatelet dimension distribution is a tunable property (grade dependent).



TEM image and diffraction pattern of monolayer graphene nanosheet

- ▶ The left image is a close-up HRTEM image displaying a monolayer graphene nanosheet.
- ▶ Nanosheet under focus has planar dimensions of approximately 1.5 μm .
- ▶ The thickness of the nanosheet is approximately 0.4 nm.
- ▶ The right image is the TEM diffraction image of the nanosheet in the left image.
- ▶ The diffraction pattern displays the characteristic hexagonal packing image of monolayer graphene.

FOR ADDITIONAL INFORMATION AND PRICING, PLEASE CONTACT:

CELTIG LLC

917 Andover View Ln.

Knoxville, TN 37922

inquiries@celtig.com

Tel: 844-4CELTIG, Fax: 865-622-9818

www.celtig.com



LIMITED WARRANTY INFORMATION:

The information contained herein is offered in good faith and is believed to be accurate at the time of printing. CELTIG LLC assumes no liability for the information contained in this product information sheet. See the associated Safety Data Sheet (SDS) for more product information. Cicarbo Graphene Nanomaterials, CELTIG, and the CELTIG logos have been filed as trademarks with the USPTO. All material in this document is copyright of CELTIG LLC, ©2015, 2016, all rights reserved.